

ALDA


keep your kitchen alive

BUILT-IN HOB


— *inspired cooking*

USER'S GUIDE


KNOW YOUR BUILT-IN HOB




BHA - 160 TR




BHA - 163 TR




BHA - 164 TR



BHA - 173 TR



BHA - 174 TR





BHA - 191 TR


1. Auxiliary burner
2. Semi-rapid burner
3. Rapid burner
4. Triple Ring burner
5. Front left burner knob

6. Front right burner knob
7. Back left burner knob
8. Back right burner knob
9. Side burner knob
10. Centre Burner knob

HOW TO SET UP



- Unpack the hob and remove all the packaging material.
- Cut an opening into the work surface, as per the measures W1 x D1 provided in the specifications table.
- In order to prevent liquids from accidentally leaking into the kitchen unit underneath, the appliance is equipped with a special seal. Stretch out the seal along the edge of the opening, taking care to overlap the joining points.
- Insert the hob into the opening in the work surface. With a screwdriver assemble the plate A with the special screw B.



- Take a flexible tube of an approved brand, which is gas resistant. Make sure it is not longer than a metre.
- Connect the flexible tube from the cylinder to the inlet nozzle of the cooktop. Push it as far as it will go. The tube should not be twisted, looped sharply or put under pressure. It should be kept away from any source of heat.
- If the hob requires electrical connection, plug the cable at the back of the unit. Earth the green/yellow coated cable.

HOW TO USE YOUR BUILT-IN HOB

- The Built-in Hobs are provided with integrated auto ignition. Just turn the knob to put on the flame.
- While cooking make sure the food being cooked does not overflow as it may choke the burner pores or extinguish the flame.
- After cooking, turn the knob to the 'OFF' position, to extinguish the flame.
- **Although the glass used in the product is toughened (tempered) but it is not unbreakable, therefore it should be handled carefully. It may break because of exposure to sudden extreme temperature's impact, due to sudden fall of a heavy or pointed object and certain kind of stresses. In the unlikely event of breakage of glass please note that it is not covered under warranty and will be replaced on payment basis only. Alda will not be responsible for injury or damage to any person (s) or property as a result of the breakage of the glass.**
- During cooking, ensure that the ingredients being cooked do not overflow, which may extinguish the flame or choke the burner ports.
- Before igniting the burners ensure that the burner and cover are properly placed in position. If they are not kept properly the burner might get deformed. (Such deformation is not covered under guarantee).
- In case of leakage of gas or any other defect, report to your gas dealer and get the Built-in-Hob checked/rectified by an authorised person only.
- The Built-in Hob has burners of different sizes to save fuel, use the burner which is the most appropriate to the pan size.
- Use a damp cloth to clean your Built-in Hob.
- Before carrying out any cleaning operation disconnect the appliance from the electric mains and turn off the main tap which supplies the appliance with gas. The burner heads, enamelled steel grills, enamelled lids and flame dividers must be cleaned periodically with warm soapy water, rinsed and dried well. Any liquid which overflows from the pan must always be removed with a cloth.
- Make sure that there are no inflammables near the Built-in Hob.
- When the Built-in Hob is in use check from time to time that it burns normally.
- The paint of pan supports will burn off from the tips which are in constant touch with the flame in the first few hours of cooking
- The burner covers are vitreous enamelled and will tend to lose the colour and shine after some use. Also in case some cold liquid spills, while these covers are very hot, the vitreous enamel may develop some cracks. This will not be covered under warranty.
- The hob is designed for the use with LPG and converting it to natural gas may affect the efficiency of the burners and the auto ignition.

SPECIFICATIONS

A. BURNER RATINGS

Model	Auxiliary Burner		Semi Rapid Burner		Rapid Burner		Triple Ring Burner		Total Gas Rating	
	g/h	Kcal/h	g/h	Kcal/h	g/h	Kcal/h	g/h	Kcal/h	g/h	Kcal/h
BHA 160 TR	74	804	123	1340	-	-	221	2412	541	5896
BHA 163 TR	-	-	123	1340	-	-	221	2412	467	5092
BHA 164 TR	74	804	123	1340	-	-	221	2412	541	5896
BHA 173 TR	74	804	-	-	172	1876	221	2412	467	5092
BHA 174 TR	-	-	123	1340	172	1876	221	2412	639	6968
BHA 191 TR	74	804	123	1340	172	1876	221	2412	713	7772

Subject to change without prior notice

B. OVERALL DIMENSIONS (mm)

Model	Width	Depth	Opening W1 x D1
BHA 160 TR	655	580	543 x 468
BHA 163 TR	600	510	555 x 476
BHA 164 TR	600	510	555 x 476
BHA 173 TR	730	420	685 x 386
BHA 174 TR	700	510	655 x 476
BHA 191 TR	930	560	830 x 480

For Use with Commercial L.P.G. at 2.942 kN/m² (30gf/cm²)

WARRANTY

This Built-in Hob is fully warranted against any defect arising out of defective materials or faulty workmanship for a period of one year from the date of purchase. Should any defect develop in this built-in Hob during the warranty period, the company undertakes to get the built-in Hob or any parts thereof repaired free of charge.

WARRANTY IS NOT VALID IF

- The Built-in Hob is not used according to the directions given in the user's guide.
- Defects are caused by improper, reckless or commercial use.
- The repair work is carried out by persons not authorised by the Company.
- The serial no. has been deleted, defaced or altered.
- The Bill/Cash Memo is not presented.
- Any modification or alteration of any nature is made in the Built-in-Hob.
- The warranty will not cover normal wear & tear of the product.
- The breakage of glass due to any reason whatsoever is not covered under warranty

The manufacturer is not responsible for any consequential losses arising out of misuse of the appliance or due to non-observance of necessary precautions in using L.P. Gas/Electric Power.

BUILT-IN HOB _____

SERIAL NO. _____ BILL NO. _____

DATE OF PURCHASE _____

NAME OF OWNER _____

ADDRESS _____

DEALER'S STAMP & SIGNATURE

ALDA
Keep your kitchen alive

Manufactured & Marketed by

Glen Appliances Pvt. Ltd., EPIP Phase-II, Thana Baddi, Distt. Solan (H.P.)

H.O. - I-34, DLF Industrial Area, Phase I, Faridabad (Haryana)

Customer Care No.: 0129-2254191 Fax: 0129-227434 Helpline: 0129-2254191

E-mail: info@aldaindia.com Website: www.aldaindia.com